



**Tabela rozładowań stałym prądem Powerfit S500**

Prąd rozładowania w [A] do 1,95 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	35,0	34,0	29,0	25,0	22,0	17,3	13,1	10,7	6,3	4,6	3,1	2,1	1,8	1,0
S512/38	48,0	47,0	41,0	35,0	31,0	25,0	19,0	15,3	9,0	6,5	4,5	3,0	2,6	1,4
S512/50	68,0	66,0	58,0	50,0	43,0	35,0	27,0	22,0	12,5	8,9	6,1	4,2	3,6	1,9
S512/60	102,0	95,0	79,0	65,0	55,0	43,0	31,5	24,7	14,9	11,0	7,3	4,9	4,2	2,2
S512/92	106,0	100,0	87,0	75,0	68,0	56,5	44,0	36,0	22,0	16,2	10,5	7,2	6,4	3,4
S512/130	152,0	149,0	133,0	118,0	105,0	86,0	66,0	54,0	30,8	23,5	15,3	10,4	9,1	4,8
S506/185	186,0	184,0	180,0	163,0	148,0	123,0	95,0	78,0	46,0	32,0	21,0	14,3	13,0	6,9

Prąd rozładowania w [A] do 1,90 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	56,0	50,0	39,0	31,0	26,0	20,1	15,4	12,6	7,7	5,8	3,7	2,4	2,1	1,1
S512/38	78,0	70,0	54,0	44,0	37,0	29,0	22,0	18,0	11,3	8,4	5,6	3,7	3,2	1,7
S512/50	111,0	99,0	77,0	63,0	53,0	41,0	31,5	26,3	15,3	10,7	7,6	5,0	4,3	2,3
S512/60	152,0	136,0	103,0	81,0	67,0	51,0	37,5	29,7	18,5	13,6	9,0	5,9	4,9	2,6
S512/92	156,0	141,0	113,0	94,0	82,0	66,0	50,5	42,0	26,0	19,0	12,5	8,7	7,7	4,1
S512/130	232,0	220,0	182,0	151,0	130,0	103,0	78,5	64,0	37,8	28,0	18,8	12,4	10,8	5,7
S506/185	285,0	272,0	241,0	209,0	184,0	146,0	112,0	91,0	52,7	37,4	24,5	16,8	15,4	8,2



**Tabela rozładowań stałym prądem Powerfit S500**

Prąd rozładowania w [A] do 1,85 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	76,0	64,0	47,0	36,5	30,0	22,7	17,1	14,0	8,3	6,3	4,0	2,6	2,2	1,2
S512/38	108,0	90,0	65,0	52,0	43,0	32,0	24,5	20,0	12,5	9,4	6,1	4,0	3,4	1,8
S512/50	153,0	129,0	94,0	73,0	61,0	46,0	35,0	28,5	16,9	12,2	8,3	5,5	4,5	2,4
S512/60	198,0	168,0	122,0	95,0	78,0	57,0	41,5	33,6	20,4	15,1	9,8	6,4	5,3	2,8
S512/92	201,0	176,0	136,0	111,0	94,0	74,0	56,0	47,0	28,5	21,0	13,8	9,4	8,1	4,3
S512/130	312,0	283,0	225,0	181,0	150,0	113,0	86,0	71,0	43,0	31,4	20,8	13,8	11,4	6,0
S506/185	381,0	354,0	296,0	250,0	214,0	166,0	123,5	100,0	57,8	41,0	27,8	18,8	16,2	8,6

Prąd rozładowania w [A] do 1,80 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	92,0	76,0	52,0	40,0	32,5	24,7	18,2	14,9	9,0	6,8	4,2	2,7	2,3	1,2
S512/38	131,0	108,0	75,0	58,0	48,0	36,0	27,0	21,8	13,4	10,2	6,5	4,2	3,5	1,9
S512/50	181,0	151,0	107,0	83,0	68,0	51,0	38,0	30,5	18,4	13,6	8,7	5,7	4,7	2,5
S512/60	231,0	190,0	134,0	104,0	84,0	61,5	45,0	36,4	21,8	16,0	10,5	6,8	5,6	3,0
S512/92	236,0	205,0	155,0	123,0	104,0	80,0	60,0	49,7	29,5	21,9	14,5	9,9	8,5	4,5
S512/130	382,0	336,0	257,0	199,0	163,0	122,0	91,0	74,0	45,0	33,7	21,8	14,3	11,8	6,2
S506/185	468,0	417,0	333,0	272,0	231,0	179,0	133,0	106,0	61,2	44,2	29,2	19,7	17,0	9,0



**Tabela rozładowań stałym prądem Powerfit S500**

Prąd rozładowania w [A] do 1,75 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	104,0	83,0	56,0	43,0	34,5	25,7	18,8	15,1	9,2	6,9	4,3	2,8	2,4	1,3
S512/38	147,0	118,0	82,0	62,0	50,0	37,0	27,5	22,3	13,6	10,4	6,6	4,3	3,6	1,9
S512/50	206,0	168,0	116,0	88,0	71,0	53,0	39,0	31,0	18,9	13,9	8,9	5,8	4,8	2,6
S512/60	256,0	208,0	145,0	109,0	89,0	64,5	47,0	38,3	22,4	16,5	10,7	7,0	5,8	3,1
S512/92	269,0	226,0	164,0	130,0	108,0	82,0	62,0	51,0	30,5	22,6	14,9	10,2	8,7	4,6
S512/130	440,0	384,0	276,0	215,0	174,0	128,0	94,0	77,0	46,4	34,8	22,3	14,6	12,1	6,4
S506/185	529,0	467,0	362,0	291,0	245,0	187,0	139,0	110,0	63,3	45,5	30,0	20,2	17,4	9,3

Prąd rozładowania w [A] do 1,70 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	112,0	89,0	60,0	45,0	36,5	26,5	19,2	15,3	9,3	7,0	4,4	2,9	2,4	1,3
S512/38	160,0	128,0	86,0	65,0	52,0	38,0	28,0	22,7	13,8	10,5	6,7	4,4	3,7	2,0
S512/50	223,0	181,0	121,0	92,0	74,0	54,5	40,0	31,5	19,1	14,1	9,0	5,9	4,9	2,6
S512/60	276,0	223,0	152,0	114,0	92,0	66,5	49,0	39,2	23,0	17,0	10,8	7,1	5,9	3,2
S512/92	309,0	253,0	175,0	136,0	112,0	84,0	63,5	52,3	31,3	23,2	15,3	10,3	8,8	4,7
S512/130	479,0	412,0	293,0	223,0	179,0	133,0	97,0	78,0	47,2	35,6	22,7	14,8	12,3	6,6
S506/185	583,0	512,0	389,0	308,0	253,0	192,0	142,0	112,0	64,6	46,3	30,7	20,6	17,8	9,4

# Powerfit S500



Tabela rozładowań stałym prądem Powerfit S500

Prąd rozładowania w [A] do 1,65 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	119,0	94,0	62,0	46,0	37,5	27,2	19,6	15,5	9,4	7,0	4,4	2,9	2,4	1,3
S512/38	169,0	134,0	88,0	66,0	53,0	39,0	28,5	23,0	14,0	10,6	6,8	4,4	3,7	2,0
S512/50	238,0	190,0	126,0	95,0	76,0	55,5	40,5	32,0	19,3	14,3	9,1	5,9	4,9	2,6
S512/60	297,0	237,0	158,0	119,0	95,0	68,5	50,0	39,8	23,3	17,3	10,9	7,1	5,9	3,2
S512/92	347,0	279,0	185,0	141,0	115,0	86,0	65,0	53,6	32,0	23,6	15,4	10,4	8,8	4,7
S512/130	506,0	432,0	303,0	230,0	186,0	136,0	99,0	79,0	47,8	36,2	22,9	14,9	12,9	6,7
S506/185	643,0	555,0	404,0	316,0	260,0	196,0	144,0	114,0	65,8	47,3	30,9	20,8	17,9	9,5

Prąd rozładowania w [A] do 1,60 V/ogniwo														
Typ	3 min	5 min	10 min	15 min	20 min	30 min	45 min	1h	2h	3h	5h	8h	10h	20h
S512/25	123,0	97,0	64,0	47,0	38,5	27,9	19,9	15,8	9,5	7,0	4,4	2,9	2,4	1,3
S512/38	174,0	138,0	90,0	67,0	54,0	40,0	29,0	23,2	14,1	10,7	6,8	4,4	3,7	2,0
S512/50	248,0	197,0	130,0	97,0	77,0	56,5	41,0	32,5	19,5	14,4	9,1	5,9	4,9	2,6
S512/60	311,0	247,0	162,0	122,0	97,0	70,5	51,0	40,8	23,5	17,4	10,9	7,1	5,9	3,2
S512/92	370,0	292,0	192,0	145,0	117,0	87,5	66,0	54,4	32,3	23,8	15,4	10,4	8,8	4,7
S512/130	519,0	441,0	312,0	237,0	190,0	138,0	100,0	80,0	48,4	26,6	23,1	15,0	12,5	6,7
S506/185	678,0	581,0	419,0	328,0	267,0	199,0	146,0	116,0	66,3	47,6	31,0	20,9	17,9	9,5